



Top Ten Ways to Save Energy at Home



1. Cool your home at 78 degree or warmer with the thermostat fan switch on "auto." For additional savings, raise your thermostat to 82 degrees or warmer when you're away from home.
2. Heat your home at 68 degrees or cooler with the thermostat fan switch on "auto." To save even more, lower your thermostat to 65 degrees or cooler at bedtime or when you're away from home.
3. Install a programmable thermostat to adjust the temperature automatically and maximize your energy savings. It also helps to maintain a comfortable temperature when you wake up or return home.
4. Clean or replace your air conditioner's filter every month to trim your cooling costs and help your unit run more efficiently.
5. Turn off your ceiling fan when you leave the room. A fan that runs constantly can cost up to \$7 a month depending on size and age.
6. Avoid pre-rinsing dishes before putting in dishwasher. It can save up to \$70 a year.
7. Adjust the water level on your washing machine to match the load size, especially when using hot water. Always use a cold rinse.
8. Clean the lint filter in your dryer before every load to dry your clothes faster and save money.
9. Use the auto sensor function on your dryer, if you have one, to conserve energy by not over-drying your clothes.
10. Lower Your Water Heater Temperature to 120 degrees F.



Be Safe, Live Well